



## NEC DX40 time AND date

Press Intercom

Dial #\*#\*

Enter system Password 9999

Press HOLD

Enter 1021-01 for System time programing.

Enter 1021-02 for System date  
programming.

1022-01 to change Daylight savings time  
settings

Enter 1511-02 to change clock format.

## NEC UNIVERGE TIME CHANGE

Change time Press **SPEAKER** key, enter  
**728**

Dial **2 digits** for the hour ( must be in 24hr  
clock time )

Dial **2 digits** for the minutes  
Press **SPEAKER**.